



CANDLE REFILL INSTRUCTIONS

Step One: Prepare Candle Container

- Wash and Dry candle container
- Your container should be the Farm to Wick container or a container that is food & microwave safe
- Take your round wick sticker and remove the front tabbed paper.
- Place silver sided wick tab on the sticky side of the sticker
- Remove paper sticker backing
- Place the wick in the center of your container, pressing down on the silver rim to ensure the wick is secure
- Thread popsicle stick through the wick, allowing the popsicle stick to rest on top of the container so the wick will be centered

Step Two: Melting Wax

- Soften wax in the microwave for 1 minute
- Microwave in increments of 30 seconds (similar to melting chocolate), stirring after each round
- When finished, the wax will be yellow.

Step Three: Pour Your Wax

- Pour wax into container
- Let set until wax is creamy white.
- We recommend not burning your candle for 24 hours, to ensure the candle is completely set up.